



## INSERTING ELASTIC IN BEARD MASK



- HEM THE OUTER EDGE OF THE MASK BY MAKING THE FIRST FOLD ON LINE A AND SECOND FOLD ON LINE B. (MAKE HEM FOLDS TO THE INSIDE OF THE MASK.)



LEAVE A 2 CM / 1 INCH OPENING THROUGH WHICH YOU WILL INSERT THE ELASTIC.

- STITCH FIRST THE AREA WHERE THE EAR WILL BE, (75 mm / 3 inch) NO ELASTIC INSERTED HERE.
- LEAVE A 20mm / 1 INCH OPENING ON EACH SIDE, THROUGH WHICH THE ELASTIC WILL BE INSERTED AND CONTINUE HEMMING ALL THE WAY AROUND.
- CUT A LENGTH OF ELASTIC  $\pm$  230mm / 9 INCH FOR UNDER THE CHIN FROM EAR LOBE TO EAR LOBE.
- INSERT THE ELASTIC IN ONE OPENING, THREAD THROUGH AND OUT THE OTHER OPENING. SECURE ELASTIC WITH A PIN ON EACH END AND STITCH IN PLACE.
- STITCH OPENINGS SHUT.